# FORM MASKING TAPE/ **PART NO. 1019**





### **STEP 1**

Tear off the required length and remove the release liner to expose the adhesive.







# **STEP 4**

Once the door is shut and the vehicle masked, spray the required area. The product will protect the interior from overspray, seamlessly leaving no paint edges.

To see a full tutorial on how to use this product, simply scan the QR code with the camera on your smart phone.



# For more information call +44 (0)1625 618185 or Email info@jtape.com

Important Notice to Purchaser: JTAPE MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. User is responsible for determining whether the JTAPE product is fit for a particular purpose and suitable for user's application. Please remember that many factors can affect the use and performance of a JTAPE Automotive product in a particular application. The materials to be bonded to the product, the conditions in which the product is used, and the time and mental conditions, in which the product is expected to perform are among the many factors that can affect the use and performance of a JTAPE Automotive product, some of which are uniquely within the user's knowledge and control. It is essential that the user evaluate the JTAPE ve product to determine whether it is fit for a particular purpose and suitable for user's methods of application. Limitation of Remedies and Liability: If the JTAPE product is proved to be defective. THE EXCLUSIVE REMEDY, AT JTAPE'S OPTION, SHALL BE TO REFUND THE PURCHASE PRICE OF OR TO REPAIR OR REPLACE THE DEFECTIVE JTAPE PRODUCT. JTAPE shall not otherwise be liable for loss or damages, whether direct, indirect special, incidental, or consequential, regardless of the legal theory asserted, including negligence, warranty, or strict liability



#### **AREAS OF APPLICATION**

B and C Post Bonnet/Hood Boot/Trunk

# **STEP 2**

TAPE

Position the tape along the edge of the panel.

CINTA DE FORMA (\*) 9mm x 25m | 3/5" x 81



## **STEP 3**

Apply pressure to secure in place.



# **STEP 5**

Upon removal, stretch the product to ensure clean removal, with no residue left behind.

#### www.jtape.com